


GARMIN®



GARMIN DASH CAM™ 46/56/66W

Owner's Manual

© 2019 Garmin Ltd. or its subsidiaries

All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to www.garmin.com for current updates and supplemental information concerning the use of this product.

Garmin® and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. Garmin Dash Cam™, Garmin Express™, and Travelapse™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The BLUETOOTH® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Garmin is under license. microSD® and the microSD logo are trademarks of SD-3C, LLC. Wi-Fi® is a registered mark of Wi-Fi Alliance Corporation.

Table of Contents


Getting Started	1
Device Overview	1
Installing a Memory Card	1
Installing the Device on Your Windshield	1
Connecting the Device to Vehicle Power	1
Setting the Camera Placement	2
Turning On the Device Manually	2
Turning Off the Device Manually	2
Main Menu	2
Dash Cam Recording	2
Saving a Video Recording	2
Event Detection	2
Turning Audio Recording On or Off	3
Taking a Photo	3
Travelapse	3
Viewing Videos and Pictures	3
Saving Unsaved Video Footage	3
Deleting a Video or Photo	3
Videos and Photos on Your Computer	3
Driver Awareness Features and Alerts	3
Forward Collision Warning System	4
Lane Departure Warning System	4
Go Alert	4
Red Light and Speed Cameras	5
Voice Control	5
Controlling the Camera Using Voice Commands	5
Turning Voice Control On or Off	5
Voice Control Tips	5
Pairing with Your Smartphone	5
Viewing Videos and Photos on Your Smartphone	5
Trimming and Exporting a Video	5
Multiple Camera Network	5
Camera Settings in the Garmin Drive App	6
Settings	6
Camera Settings	6
Driver Assistance Settings	6
System Settings	6
Device Information	7
Cleaning the Camera Lens	7
Product Updates	7
Garmin Support Center	7
Viewing E-Label Regulatory and Compliance Information	7
Restarting the Device	7
Specifications	7
Memory Card Specifications	7
Appendix	7
Recording Videos While Parked	7
Troubleshooting	8
My camera feels warm while it is operating	8
My memory card has degraded and needs to be replaced	8
My video recordings are blurry	8
My video recordings are choppy or incomplete	8
Index	9

Getting Started

⚠ WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Device Overview



①		Press to turn the device on. Hold for 3 seconds to turn the device off. Select to return to the previous page.
②		Select to scroll through menus or pages.
③		Select to scroll through menus or pages.
④		From the viewfinder, select to save a photo. Hold to save a video clip. Select to choose an option in a menu.

Installing a Memory Card

To record video, you must install a compatible memory card (*Memory Card Specifications*, page 7).

- 1 Insert the memory card ① into the slot ②.



- 2 Press it in until it clicks.

Formatting the Memory Card

The camera requires a memory card formatted using the FAT32 file system. You can use the camera to format your card using this file system.

You should format your memory card at least one time every 6 months to help extend the useful life of the memory card. You must also format a brand new memory card if it is not formatted using the FAT32 file system.

NOTE: Formatting the memory card deletes all videos, photos, and data on the card.

- 1 Connect the camera to power.
- 2 Select **Settings > Camera > Format Card**.
- 3 Keep the camera connected to power until the formatting is complete.

When formatting is complete, the camera displays a message and begins recording.

Removing the Memory Card

NOTICE

Removing the memory card while the device is turned on can result in a loss of data or damage to the device.

- 1 Turn off the device.
- 2 Press the card in until it clicks.
- 3 Release the card.
The card ejects from the slot.

Installing the Device on Your Windshield

NOTICE

The adhesive mount is intended for a long-term installation and can be difficult to remove. You should carefully consider the mounting location before you install the mount.

Before you can install the adhesive mount onto your windshield, the ambient temperature must be from 21° to 38°C (from 70° to 100°F).

- 1 Clean the windshield using water or alcohol, and a lint-free cloth.
The windshield must be free of dust, wax, oils, or coatings.
- 2 Remove the protective film from the mount adhesive.



- 3 Position the mount over the mounting location.
TIP: The adhesive is extremely sticky. Avoid touching the adhesive to the windshield until the mount is properly positioned and aligned.
- 4 Press the mount firmly onto the windshield, and maintain pressure for 30 seconds.
This helps to ensure the mount adhesive has proper contact with the windshield.



Connecting the Device to Vehicle Power

- 1 Plug the power cable into the USB port on the device.



2 Route the power cable to your vehicle power outlet.

You can use either of the included cables to provide power to the camera. The longer, lightweight power cable is designed to be routed out of sight. To hide the 4 m (13 ft.) cable, route it behind the vehicle trim along the windshield, doorframe, or dash.



- 3** Plug the Garmin Dash Cam power cable into the included power adapter.
 - 4** Plug the power adapter into a power outlet in your vehicle.
 - 5** If necessary, turn on the vehicle ignition switch to provide power to the power outlet in your vehicle.
- The device turns on.

Setting the Camera Placement

You can mount the device in the left, center, or right of your windshield. For the best performance, you should set the Camera Placement option to indicate the location of your device in the vehicle.

- 1** Select **Settings > Driver Assistance > Camera Placement**.
- 2** Select **Horizontal Placement**, and select the horizontal placement of your camera.
- 3** Select **Vehicle Height**.
- 4** Select an option:
 - If you are driving a large vehicle, like a full size van or truck, select **Tall**.
 - If you are driving a car, select **Normal**.

Turning On the Device Manually

Before you turn on the device using battery power, you should fully charge the battery.

NOTE: When the device is connected to an ignition-switched power outlet, it turns on automatically when you turn on the vehicle.

- Select .
- The device turns on.

Turning Off the Device Manually

NOTE: When the device is connected to an ignition-switched power outlet, it turns off automatically when you turn off the vehicle.

- Hold  for 3 seconds.
- The device turns off.

Main Menu

From the viewfinder, press  or  to scroll through the main menu, and press  to open a menu item.

Gallery: Allows you to view and manage recorded video and photos ([Viewing Videos and Pictures, page 3](#)).

Travelapse: Allows you to start and stop Travelapse™ recording ([Travelapse, page 3](#)).

Voice Control: Allows you to enable and disable the voice control features ([Voice Control, page 5](#)).

Garmin Drive App: Allows you to pair your camera with your smartphone and the Garmin Drive™ app ([Pairing with Your Smartphone, page 5](#)).

Settings: Allows you to set up camera features, change system settings, and view system information ([Settings, page 6](#)).

Dash Cam Recording

NOTICE

Some jurisdictions regulate or prohibit use of this device. It is your responsibility to know and comply with applicable laws and rights to privacy in jurisdictions where you plan to use this device.

The dash cam records video to the camera memory card ([Installing a Memory Card, page 1](#)). By default, the device immediately starts recording video when it turns on, and it continues recording until it is turned off. If the memory card is full, the device automatically deletes the oldest unsaved video to create space for new video.

When the option to promptly delete unsaved video is enabled, the device continually deletes unsaved video more than three minutes old and deletes all unsaved video each time it is powered off. This feature is available only for specific regions and is enabled by default for some of those regions. When the camera is set to a supported region, you can enable or disable this feature in the camera settings ([Camera Settings, page 6](#)).

You can save a video recording to prevent it from being overwritten or deleted ([Saving Unsaved Video Footage, page 3](#)).

Saving a Video Recording

By default, the device uses a sensor to detect a possible incident and automatically saves video footage before, during, and after the detected event. You can also save video files manually at any time.

- Hold .

The device saves the video footage before, during, and after you hold .

The memory card has limited storage. After you save a video recording, you should transfer the recording to your computer ([Videos and Photos on Your Computer, page 3](#)) or to your smartphone ([Trimming and Exporting a Video, page 5](#)).

Event Detection

By default, the device uses a sensor to detect possible incidents and saves video footage automatically before, during, and after the detected event. The video footage is stamped with the time, date, and location of the event.

Turning Audio Recording On or Off

NOTICE

Some jurisdictions may prohibit recording audio in the vehicle or may require that all passengers have knowledge of the recording and provide consent before you record audio in the vehicle. It is your responsibility to know and follow all laws and restrictions for your jurisdiction.

The device can record audio using the integrated microphone while recording video. You can turn audio recording on or off at any time.

Select **Settings > Camera > Record Audio**.

Taking a Photo

From the viewfinder, select .

The device saves the photo to the memory card.

Travelapse

The Travelapse feature captures a fast-motion video of your trip, which allows you to share a short video of all the places you traveled. Recording Travelapse does not stop dash cam recording.

NOTE: Travelapse recording is not available when the option to promptly delete unsaved video is enabled (*Camera Settings, page 6*).

Recording a Travelapse Video

You can manually start and stop Travelapse recording at any time using the main menu or voice commands.

NOTE: The device continues to record regular dash cam footage while recording a Travelapse video.

- To start recording a Travelapse video, select an option:
 - From the main menu, select **Travelapse > Start**.
 - Say **OK, Garmin, Start Travelapse**.
- To stop Travelapse recording, select an option:
 - From the main menu, select **Travelapse > Stop**.
 - Say **OK, Garmin, Stop Travelapse**.

Viewing Videos and Pictures

NOTE: The device stops recording and alerts are disabled while viewing videos or pictures.

1 Select  > **Gallery**.

2 Select an option:

NOTE: Unsaved videos and Travelapse videos are not available when the option to promptly delete unsaved video is enabled (*Camera Settings, page 6*).

- To view videos you saved, select **Saved Videos**.
- To view parked videos you saved, select **Parked Videos**.
- To view saved photos, select **Pictures**.
- To view Travelapse videos, select **Travelapse**.
- To view recent video footage that has not been saved, select **Unsaved Videos**.

3 Select a video or photo.

Saving Unsaved Video Footage

You can view your unsaved temporary footage in the gallery and save video clips from the unsaved footage. This feature is not available when the option to promptly delete unsaved video is enabled (*Camera Settings, page 6*).

1 Select  > **Gallery > Unsaved Videos**.

2 Select a day and time.

The unsaved video for that timeframe starts playing.

3 Hold  or  to move backward or forward through the video.

While you hold the button, the device increases the speed at which it moves through the video. The timestamp appears in the lower-left corner of the video.

4 When you find the video footage you want to save, press  > **Save**.

The device saves a three-minute video clip.

Deleting a Video or Photo

- While viewing a video, select  > **Delete > Yes**.
- While viewing a photo, select  > **Yes**.

Videos and Photos on Your Computer

NOTE: Some media players might not support high-resolution playback.

Videos and photos are stored in the DCIM directory on the camera memory card. Videos are stored in MP4 file format, and photos are stored in JPG format. You can view and transfer photos and videos by connecting the memory card or the device to your computer (*Connecting the Camera to Your Computer, page 3*).

The videos and photos are sorted into several folders.

NOTE: Unsaved videos and Travelapse videos are not available when the option to promptly delete unsaved video is enabled (*Camera Settings, page 6*).

100EVENT: Contains videos saved automatically when the device detects an incident.

101PHOTO: Contains photos.

102SAVED: Contains videos saved manually by the user.

103PARKM: Contains videos saved while parked.

104TLPSE: Contains Travelapse videos.

105UNSV: Contains unsaved video footage. The device overwrites the oldest unsaved video when the storage space for unsaved videos is full.

Connecting the Camera to Your Computer

You can connect the camera to your computer to install software updates or transfer videos and photos to your computer. You should connect to your computer using the shorter 1.5 m (5 ft.) micro-USB data cable included with your device.

NOTE: The longer power cable included with your device is intended for power only, and it cannot be used to connect to your computer.

1 Plug the small end of the data cable into the micro-USB port on the camera.

2 Plug the larger end of the data cable into a USB port on your computer.

Depending on your computer operating system, the device appears as either a removable drive or a removable volume on your computer.

Driver Awareness Features and Alerts

Your camera provides features that can help encourage more attentive driving, even when you are driving in a familiar area. The device plays an audible tone or message and displays information for each alert. You can enable or disable the audible tone for some types of driver alerts.

Forward collision warning: The device alerts you when it detects that you are not maintaining a safe distance between your vehicle and the vehicle in front of you.

Lane departure warning: The device alerts you when it detects you may be crossing a lane boundary unintentionally.

Go alert: The device plays a tone and displays an alert when stopped traffic starts moving.

Speed cameras: The device plays a tone and displays the speed limit and the distance to the speed camera.

Red light cameras: The device plays a tone and displays the distance to the red light camera.

Forward Collision Warning System


⚠ WARNING

The forward collision warning system (FCWS) feature is for information only and does not replace your responsibility to observe all road and driving conditions, abide by all traffic regulations, and use safe driving judgment at all times. The FCWS relies on the camera to provide a warning of upcoming vehicles and, as a result, may have limited functionality in low visibility conditions. For more information, go to garmin.com/warnings.

NOTE: This feature is not available in all areas or for all product models.

The FCWS feature alerts you when the device detects that you are not maintaining a safe distance between your vehicle and the vehicle in front of you. The device determines your vehicle speed using GPS, and it calculates an estimated safe following distance based on your speed. The FCWS activates automatically when your vehicle speed exceeds 48 km/hr (30 mph).

When the device detects that you are too close to the vehicle ahead of you, the device plays an audible alert, and a warning appears on the screen.



Forward Collision Warning System Performance Tips

Several factors affect the performance of the forward collision warning system (FCWS). Some conditions may prevent the FCWS feature from detecting a vehicle ahead of you.

- The FCWS feature activates only when your vehicle speed exceeds 50 km/h (30 mph).
- The FCWS feature may not detect a vehicle ahead of you when the camera's view of the vehicle is obscured by rain, fog, snow, sun or headlight glare, or darkness.
- The FCWS feature may not function properly if the camera is incorrectly aligned ([Setting the Camera Placement, page 2](#)).
- The FCWS feature may not detect vehicles greater than 40 m (130 ft.) away or closer than 5 m (16 ft.).
- The FCWS feature may not function properly if the camera placement settings do not correctly indicate your vehicle height or the placement of your device in the vehicle ([Setting the Camera Placement, page 2](#)).

Lane Departure Warning System

⚠ WARNING

The lane departure warning system (LDWS) feature is for information only and does not replace your responsibility to observe all road and driving conditions, abide by all traffic regulations, and use safe driving judgment at all times. The LDWS relies on the camera to provide warnings for lane markers and, as a result, may have limited functionality in low

visibility conditions. For more information, go to garmin.com/warnings.

The LDWS feature alerts you when the device detects you may be crossing a lane boundary unintentionally. For example, the device alerts you if you cross some solid painted lane boundaries. The LDWS feature provides alerts only when your vehicle speed exceeds 64 km/h (40 mph). The alert appears on the left or right side of the screen to indicate which lane boundary you crossed.



NOTE: For the best LDWS performance, you should set the Camera Placement option to indicate the location of the device in your vehicle.

Lane Departure Warning Performance Tips

Several factors affect the performance of the lane departure warning system (LDWS). Some conditions may prevent the LDWS feature from detecting lane departures.

- The LDWS feature provides alerts only when your vehicle speed exceeds 65 km/h (40 mph).
- The LDWS feature may not function properly if the camera is incorrectly aligned.
- The LDWS feature may not function properly if the camera placement settings do not correctly indicate your vehicle height or the placement of your device in the vehicle ([Setting the Camera Placement, page 2](#)).
- The LDWS feature requires a clear, continuous view of the lane divider lines.
 - Lane departures may not be detected when divider lines are obscured by rain, fog, snow, extreme shadows, sun or headlight glare, road construction, or any other visual obstruction.
 - Lane departures may not be detected if lane divider lines are misaligned, missing, or heavily worn.
- The LDWS feature may not detect lane departures on extremely wide, narrow, or winding roads.

Go Alert

The go alert plays a tone and displays an alert when stopped traffic ahead of your vehicle starts moving again. This alert appears only after the vehicle ahead has moved a substantial distance and your vehicle has remained stopped. This can be useful at stop lights or in traffic delays. This feature uses the dash camera to detect the stopped or moving vehicle and requires a clear view of the road.



Red Light and Speed Cameras

NOTICE

Garmin® is not responsible for the accuracy of or the consequences of using a red light or speed camera database.

NOTE: This feature is not available for all regions or product models.

Information about red light and speed camera locations is available in some areas for some product models. The device alerts you when you approach a reported speed or red light camera.

- You can use the Garmin Express™ software (garmin.com/express) to update the camera database stored on your device. You should update your device frequently to receive the most up-to-date camera information.

Voice Control

The voice control feature allows you to control your camera by saying words and commands.

NOTE: The voice control feature is not available for all languages. You can use this feature while the interface is set to an unsupported language, but you must speak the commands in English.

Controlling the Camera Using Voice Commands

- Say **OK, Garmin** to activate the voice control feature.
The camera plays a tone and starts listening for a command.
- Say a command:
 - To save a video, say **Save Video**.
 - To take a picture, say **Take a Picture**.
 - To record audio with the video, say **Record Audio**.
 - To record video without audio, say **Stop Audio**.
 - To start Travelapse recording, say **Start Travelapse**.
 - To stop Travelapse recording, say **Stop Travelapse**.

The camera plays a tone when it recognizes your command.

Turning Voice Control On or Off

Select **∨ > Voice Control > Settings > Disable**.

Voice Control Tips

- Speak in a normal voice directed at the device.
- Reduce background noise to increase the accuracy of the voice recognition.
- Before each command, say **OK, Garmin**.
- Listen for a tone to confirm that the camera successfully recognized a command.

Pairing with Your Smartphone

You can pair your Garmin Dash Cam camera with your smartphone and the Garmin Drive app. The Garmin Drive app allows you to set up a multiple-camera network, change camera settings, and view, edit, and save photos and videos.

- From the app store on your smartphone, install the Garmin Drive app.
- Turn on your Garmin Dash Cam camera, and place the device and your smartphone within 3 m (10 ft.) of each other.
- On your phone, open the Garmin Drive app.
- Select an option:

- If this is the first Garmin device you are pairing with your smartphone, accept the Garmin Drive app license agreements.
 - If you are pairing an additional Garmin device or camera with your smartphone, select **Add a Device**.
- Follow the on-screen instructions to complete the pairing and setup process.

The main app dashboard appears. After the devices are paired, they connect automatically when they are turned on and within range.

Viewing Videos and Photos on Your Smartphone

Before you can view videos and photos on your smartphone, you must pair your Garmin Dash Cam device with the Garmin Drive app ([Pairing with Your Smartphone, page 5](#)).

NOTE: The device stops recording and alerts are disabled while viewing videos or photos.

- From the Garmin Drive app on your smartphone, select **Review Footage**.
- Select an option:
 - To view a photo or video you saved, select a file from the **Saved Footage** category.
 - To view recent video footage that has not been saved, select a video from the **Temporary Footage** category.

Deleting a Video or Photo Using Your Smartphone

- When you are viewing the list of saved videos or photos on your smartphone, select **Select**.
- Select one or more files.
- Select .

Trimming and Exporting a Video

You can trim the length of your video to remove unnecessary footage before exporting it.

- From the Garmin Drive app, select **Review Footage**.
- Select a video.
- Drag the handles on the video progress bar left or right to trim the video length.
- Select **Export**.

NOTE: You must keep the app in the foreground when exporting a video.

The app exports the trimmed video to your smartphone.

Multiple Camera Network

You can pair multiple dash cameras with the Garmin Drive app. This allows you to connect to dash cameras from multiple vehicles using the same phone. It also allows you to install multiple dash cameras in the same vehicle, such as front and rear cameras, and create composite picture-in-picture videos from the simultaneous recordings. If a GPS-connected camera is part of the network, you can add location information to saved videos for all cameras on the network.

Creating Picture-in-Picture Multi-Camera Videos

Before you can use this feature, you must pair at least two cameras with the Garmin Drive app and record footage using both cameras.

The Garmin Drive app allows you to create composite, picture-in-picture videos from footage recorded at the same time on two cameras.

- From the Garmin Drive app, select **Review Footage**.
- Select a multi-camera video.

Multi-camera videos are indicated by multiple camera icons  on the video thumbnail. The app automatically

combines video recorded at the same time into one multi-camera video icon.

- 3 Select ◀ and ▶ to choose the camera footage to use for the fullscreen portion of the video.
- 4 Drag the handles on the video progress bar to the left or right to trim the video length.
- 5 Select **Continue**.
- 6 Select ◀ and ▶ to choose the camera footage to use for the picture-in-picture portion of the video.
- 7 Select the corner of the screen where you want the picture-in-picture footage to appear, and select **Export**.

NOTE: You must keep the app in the foreground when exporting a video.

The app exports the picture-in-picture video to your smartphone.

Camera Settings in the Garmin Drive App

From the Garmin Drive app, select ⚙️, and select the camera name.

Camera Setup: Provides options to choose a camera name and displays a live video feed so you can adjust the position of the camera.

Quality: Adjusts the video resolution.

Data Overlay: Adjusts the type of data displayed on videos and pictures.

Unsaved Videos: This feature is not available in all areas.

Determines when the device deletes unsaved video footage. When the **Delete When Full** option is selected, the device deletes the oldest unsaved video when the memory card storage is full. When the **Promptly Delete** option is selected, the device continually deletes unsaved video more than three minutes old and deletes all unsaved video each time it is powered off. This is useful to help protect data privacy. While the Promptly Delete option is selected, you cannot record Travelapse videos.

Travelapse: Enables or disables the Travelapse feature ([Travelapse, page 3](#)).

Units and Time: Adjusts settings for the date and time format.

About Device: Lists the camera software version and unit ID.

Format SD Card: Formats the memory card and deletes all videos, photos, and data on the card.

Restore Defaults: Restores the device to factory default settings and unpairs the device from the Garmin Drive app.

Forget Device: Unpairs the device from the Garmin Drive app.

Renaming a Camera

You can change the name of your camera to help differentiate it from other cameras in a multiple camera network.

- 1 Select ⚙️.
- 2 Select a camera.
- 3 Select **Camera Setup**.
- 4 Select a camera name from the **Camera Name** field.
TIP: You can select Custom to enter a custom camera name.

Settings

Camera Settings

Select ^ > **Settings** > **Camera**.

Resolution: Adjusts the video resolution.

Event Detection: Turns on and off event detection ([Event Detection, page 2](#)).

Record Audio: Turns on and off audio recording ([Turning Audio Recording On or Off, page 3](#)).

Data Overlay: Adjusts the type of data displayed on videos and pictures.

Unsaved Videos: This feature is not available in all areas.

Determines when the device deletes unsaved video footage. When the **Delete When Full** option is selected, the device deletes the oldest unsaved video when the memory card storage is full. When the **Promptly Delete** option is selected, the device continually deletes unsaved video more than three minutes old and deletes all unsaved video each time it is powered off. This is useful to help protect data privacy. While the Promptly Delete option is selected, you cannot record Travelapse videos or view unsaved video in the gallery.

Record After Power Loss: Sets the amount of time that the device continues to record video after power is turned off.

Record While Parked: Allows the camera to record video while the vehicle is parked and turned off, and sets the amount of time the camera remains active while parked. This feature is only available when the Dash Cam parking mode cable accessory is connected to the camera ([Recording Videos While Parked, page 7](#)).

NOTICE

Due to privacy regulations, this feature is not available in all areas. It is your responsibility to know and comply with applicable laws and rights to privacy in your jurisdiction.

Format Card: Formats the memory card and deletes all videos, photos, and data on the card.

Video Resolution Settings

You can set the resolution, frames per second (FPS), and high dynamic range (HDR) option of video recorded by the camera.

Resolution is the width and height of the video in pixels. FPS is the number of video frames captured each second. HDR combines multiple exposure levels for each video frame and can improve clarity in high contrast or low-light conditions. Settings with a higher resolution or FPS require more memory card space.

Not all settings are supported for all product models.

Select **Settings** > **Camera** > **Resolution**.

Setting	Resolution	Supported Models
1440p, 30fps, HDR	2560 × 1400 px	56/66W
1080p, 60fps	1920 × 1080 px	56/66W
1080p, 30fps, HDR	1920 × 1080 px	56/66W
1080p, 30fps	1920 × 1080 px	46
720p, 30fps, HDR	1280 × 720 px	56/66W
720p, 30fps	1280 × 720 px	46

Driver Assistance Settings

Select ^ > **Settings** > **Driver Assistance**.

Camera Placement: Allows you to indicate the placement of your device in the vehicle ([Setting the Camera Placement, page 2](#)).

Forward Collision: Adjusts the sensitivity of the FCWS feature.

Go Alert: Turns on or off the go alert display and audible alerts when traffic starts moving ([Go Alert, page 4](#)).

Lane Departure: Adjusts the lane boundary settings ([Lane Departure Warning System, page 4](#)).

Proximity Alerts: Adjusts the audible proximity alerts.

System Settings

Select ^ > **Settings** > **System**.

Volume: Adjusts the volume of the camera alerts and video playback.

Brightness: Adjusts the viewfinder display brightness.

Color Mode: Allows you to select day or night color mode. If you select the Auto option, the device automatically switches to day or night colors based on the time of day.

Display Timeout: Allows you to set the screen to stay on while the camera is receiving power or turn off after one minute of idle time. The camera continues to record while the screen is off, and the recording LED remains red to indicate the device is recording.

Setup: Allows you to set the units of measure, time, and language, and restore them to their default values.

About: Displays the camera name, software version number, the unit ID number, and information about several other software features.

Regulatory: Displays regulatory and compliance information.

Device Setup

Select **^ > Settings > System > Setup**.

Units: Sets the unit of measure used for distances.

Time: Sets the time, date, and format for the time stamp.

Language: Sets all on-screen text to the selected language.

Restore: Restores all settings to the factory default values and unpairs the camera from the Garmin Drive app. This option does not delete recorded photos and videos. To delete all photos and videos on your memory card, you can format the memory card ([Formatting the Memory Card, page 1](#)).

Device Information

Cleaning the Camera Lens

NOTICE

Avoid chemical cleaners and solvents that can damage plastic components.

You should clean the camera lens regularly to improve the quality of recorded video.

- 1 Wipe the lens with a non-scratch lens cloth, optionally dampened with isopropyl alcohol.
- 2 Allow the lens to air dry.

Product Updates

On your computer, install Garmin Express (www.garmin.com/express).

This provides easy access to these services for Garmin devices:

- Software updates
- Product registration

Setting Up Garmin Express

- 1 Connect the device to your computer using a USB cable.
- 2 Go to garmin.com/express.
- 3 Follow the on-screen instructions.

Updating Your Device Using the Garmin Drive App

The Garmin Drive app notifies you when a software update is available for your device.

- 1 In the Garmin Drive app, select **Install Now**.
The software update is sent to your device. You are notified when the transfer is complete.
- 2 Disconnect the device from power until the device turns off.
- 3 Connect the device to power.
The device installs the software update.
NOTE: Footage is not recorded while the software is updating.

Garmin Support Center

Go to support.garmin.com for help and information, such as product manuals, frequently asked questions, videos, and customer support.

Viewing E-Label Regulatory and Compliance Information

- 1 From the settings menu, scroll to the bottom of the menu.
- 2 Select **System**.
- 3 Select **Regulatory**.

Restarting the Device

You can restart your device if it stops functioning.

Hold the power key for 12 seconds.

Specifications

Operating temperature range	From -20° to 55°C (from -4° to 131°F)
Charging temperature range	From 0° to 45°C (from 32° to 113°F)
Input voltage	4.75 to 5.25 Vdc, 1 A
Wireless frequencies	2.4 GHz @ 7dBm

Memory Card Specifications

The camera requires a memory card with these specifications.

Type	microSDHC or microSDXC
Capacity	8 GB or greater
Speed class	Class 10 or higher
File system	FAT32

Appendix

Recording Videos While Parked

NOTICE

Due to privacy regulations, this feature is not available in all areas. It is your responsibility to know and comply with applicable laws and rights to privacy in your jurisdiction.

Before you can record videos while parked, you must connect your camera to the Dash Cam parking mode cable accessory ([Parking Mode Cable Wiring Diagram, page 7](#)).

The parked video recording feature allows the camera to record video automatically while your vehicle is parked.

Select **^ > Settings > Camera > Record While Parked**.

When you turn off your vehicle, the camera enters parked recording mode and automatically records video each time the camera sensor detects motion.

Parking Mode Cable Wiring Diagram



Item	Wire Color	Wire Function
①	Black	Ground
②	Yellow	Battery 12 V
③	Red	Accessory 12 V

Connecting the Parking Mode Cable Accessory to Power

⚠ CAUTION

Garmin strongly recommends having an experienced installer with the proper knowledge of electrical systems install the

device. Incorrectly wiring the power cable can result in damage to the vehicle or the battery and can cause bodily injury.

- 1 Route the parking mode cable accessory to a location in the vehicle with constant power, switched power, and a ground connection.
- 2 Connect the **BATT** wire to a constant power source.
- 3 Connect the **ACC** wire to a switched power source.
- 4 Connect the **GND** wire to the bare metal of the vehicle's chassis using an existing bolt or screw.
- 5 Plug the parking mode cable accessory into the USB port on the camera.

Troubleshooting

My camera feels warm while it is operating

It is normal for the camera to feel warm during typical use, especially while it is recording high-resolution video or transmitting a Wi-Fi® signal.

My memory card has degraded and needs to be replaced

All microSD® memory cards wear out after they are overwritten a large number of times. Periodically formatting the card can extend the useful life and improve performance. Because the dash camera records continuously, you may need to replace the memory card periodically (*Installing a Memory Card, page 1*). Your device detects memory card errors automatically and alerts you when it is time to format or replace your memory card.

You can take these actions to help extend the useful life of the memory card.

- Format the memory card at least one time every six months (*Formatting the Memory Card, page 1*).
- If the device displays a memory card error alert, first try formatting the memory card (*Formatting the Memory Card, page 1*) and then, if necessary, replace the memory card (*Installing a Memory Card, page 1*).
- Turn off the device when your vehicle is not in use.
If your device is not connected to an ignition-switched vehicle power outlet, you should turn off the device when your vehicle is not in use to prevent the dash camera from recording unneeded footage.
- Transfer saved video footage to a computer.
The memory card lasts longer when more free space is available on the card.
- Use a memory card with a higher storage capacity.
Because higher-capacity memory cards are overwritten less frequently, they usually last longer.
- Use a high-quality memory card with a speed rating of class 10 or higher.
- Purchase your replacement memory card from a high-quality manufacturer and a reputable vendor.

My video recordings are blurry

- Clean the camera lens (*Cleaning the Camera Lens, page 7*).
- Clean the windshield in front of the camera.
- Verify the area of the windshield in front of the camera is cleared by the windshield wipers, and move the device, if necessary.

My video recordings are choppy or incomplete

- For the best camera and video results, use a high-quality memory card with a speed rating of class 10 or higher.
A slower memory card may not record video quickly enough.
- If you are viewing videos on your smartphone using a wireless connection to the camera, try viewing them in another location with less wireless interference, or try transferring videos to the smartphone (*Trimming and Exporting a Video, page 5*).
- Transfer important recordings to a computer or smartphone, and format the memory card (*Formatting the Memory Card, page 1*).
- If the device displays a memory card error alert, first try formatting the memory card (*Formatting the Memory Card, page 1*) and then, if necessary, replace the memory card (*Installing a Memory Card, page 1*).
- Update your device to the latest software (*Product Updates, page 7*).

Index

A

advanced driver assistance system (ADAS) 4
alerts 3

B

Bluetooth technology, pairing a phone 5

C

camera, renaming 6
camera placement 2
cameras
dash cam 1
red light 5
speed 5
cleaning, device 7, 8
computer, connecting 3
customizing, settings 7

D

dash cam 8
memory card 1
recording audio 3
recording video 3
device overview 1
driver alerts 3, 4

E

event detection 2

F

forward collision warning system (FCWS) 3, 4

G

Garmin Express 7
updating software 7
getting started 2

L

lane departure warning system (LDWS) 3, 4

M

memory card 1, 7, 8
installing 1
microSD card 1, 7, 8
mounting, windshield 1
multiple cameras 5

P

pairing, phone 5
parking mode cable 7
phone, pairing 5
photos 2
viewing 3
power key 2

R

red light cameras 5
resetting, device 7
resolution 6

S

settings 2, 6
setup 1
smartphone features, connecting 5
software
updating 7
version 7
speed cameras 5
system 6

T

taking, photos 3
Travelapse 2, 3
troubleshooting 8

U

updating software 7

V

video
deleting 3, 5
editing 5
photos, viewing 3, 5
playing 3, 5
quality 8
recording 2, 3, 7
saving 3, 5
videos 2
voice control 2, 5
tips 5

TRA
REGISTERED No:
ER69454/19
DEALER No:
0015955/08

