



User Manual

Minibar Model No:SM40



◆ Caution and Attention

- ◇ Please read the user manual carefully before using it.
- ◇ Electrical wire is easy to be damaged by cutting, extending or heating.
- ◇ Fire and creepage will be happened if using damaged electrical wire.
- ◇ If electrical wire is damaged, please change to appropriate one or change it from factory.
- ◇ Avoiding catching fire, please don't lengthen electrical wire or using it with other appliances.
- ◇ Avoiding creepage, please don't touch plug and power switch by wet hand.
- ◇ Please use standard and qualified electrical outlet.
- ◇ Please don't maintain, repair and disassemble it by yourself.
- ◇ Please unplug electrical plug if dangerous things happen.
- ◇ Please unplug electrical plug if not using it for long time.
- ◇ Please don't store food, fruit and beverage for long time if opening it, otherwise it is easy to make bad and germ, also please don't eat them.
- ◇ Because insulation material is flammable, please keep it away from fire.

◆ How to use


- ◇ Please put it on horizontal place and make ventilation well according to our indication. Please refer to No.4 indication picture.
- ◇ Please connect with electrical outlet and check whether the lamp is light, if light, it means working.
- ◇ Closing door and working for 2 hours, then put food, fruit or beverage into it.
- ◇ Our setting inside tempture is around 8°C based on 25°C ambient temperature. It can not be adjusted.
- ◇ If need clean it, please take off plug firstly.
- ◇ Please use soft or cotton cloth to clean it.
- ◇ If need move it, please take out plug and all of food, fruit or beverage firstly.

◆ Structure




◆ How to change door

1. take out the bottom hinge.
2. take out hinge cover.
3. Take out door.
4. take out the top hinge after loosing the three screws.
5. take out hinge hole covers.
6. install door and top hinge.
7. intall bottom hinge.
8. intall hinge covers.
9. Install Hinge hole Covers.



1. bottom hinge 2. hinge cover 3. door
4. screw 5. top hinge 6. hinge hole cover

◆ Ventilation requirement



◆ Specification

Minibar	
Model No	SM40
Dimension	W400mm*D425mm*H560mm
Capacity	40L
Net Weight	12.3 kg
Rated V/Hz	220V 50/60Hz
Rated W	63W
Rated A	0.6A

◆ Trouble shooting

Doesn't Work	If power off ?
	If connnect with electrical outlet?
	If lamp is light?
	If ambient temperature is very high?
Inside Temperature is not enough	If door gasket is ok?
	If ventilation accords to our requirement (No.4 Picture)
	If ambient temperature is very high?