

Product 721141



721141 Active holder with cig-plug With USB-cable with cig-plug adapter. With tilt swivel. 2,1A charging. 12/24V.

Keep your phone's battery fully charged in an active holder, always within easy sight and reach! Neat, discreet and convenient. Custom made with a perfect, firm fit. With USB-cable with cig-plug adapter, choose to connect either to the vehicle's USB outlet or the 12/24V socket. You have full access to the camera and all buttons when the device is in the holder. It is easy to slide the device into place in the holder so it connects to the charging, and to take it out of the holder when leaving the car.

The holder is equipped with a tilt swivel so you can easily adjust the angle for better viewing, or switch between portrait and landscape mode. Tilts 17° and swivels 360°. Mounting plate 42x50 mm with AMPS-holes. Made of high grade black ABS/Acetal plastic. Made in Sweden. Attach onto a Pedestal Mount or an ProClip mounting platform.

Important note!

In order to be able to transmit audio files from your device through the USB-cable, this feature must be supported by the stereo in your car. You can easily test if this works by connecting your device to the stereo with the USB/charging cable that comes with your device. Charging through USB works regardless.

EAN: 7320287211412

Item no 721141 fits:

Samsung Galaxy A40 (SM-A405) (For all countries)

INSTALLATION INSTRUCTIONS

1.



2.



3.



4.



Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back.
2. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws.
3. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel and screw it into place. Tighten the screw firm at first, then loosen it a bit so the holder is firmly in place, but still can be adjusted.
4. The holder is in place.