

REOLINK TECHNOLOGY PTE. LTD.

3 TAI SENG AVENUE,#07-31,TAI SENG EXCHANGE, SINGAPORE 536465



FR

Cet appareil,
ses accessoires
et cordons
se recyclent

À DÉPOSER
EN MAGASIN



ou

À DÉPOSER
EN DÉCHÈTERIE



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !




PAP 22
Raccolta Carta

Reolink

Reolink Chime, Reolink Chime Plus

Operational Instructions



@ReolinkTech

<https://reolink.com>

58.03.009.0166


EN/DE/FR/IT/ES

Content

01	Device Overview	2
02	Compatibility	3
03	Setting Up the Chime	3
04	Using the Chime	7
05	Specifications	9
06	Important Safety Instructions	10
07	Legal Disclaimer	11
08	Notification of Compliance	12

01 Device Overview

- 1 Status Indicator LED
- 2 Settings Button
- 3 Ringtone Button
- 4 Volume Button



02 Compatibility

For compatibility information, please refer to:
<https://support.reolink.com/hc/en-us/articles/11613761961241/>

03 Setting Up the Chime




NOTE:


Doorbell kits that include a chime come pre-paired. Simply plug in the chime and press the doorbell button. If it rings, setup is complete and you can skip manual pairing.

To pair a separately purchased Chime, follow these steps:

1. Plug the chime into a power outlet and turn it on.
2. Press and hold the **Settings** button on the side of the chime until it beeps three times and the LED turns blue.




3. Open the Reolink App and navigate to **Doorbell Settings** > **Chime** > **Reolink Chime**. Tap **"Go to Pair,"** then follow the on-screen instructions to complete pairing.



NOTE:


1. One doorbell can pair with up to five chimes. If you need to pair multiple chimes, repeat the pairing process for each.
2. Each chime can only pair with one doorbell.
3. Reolink Chime is compatible with Reolink Video Doorbell only.

4. Once pairing is complete, press the doorbell button and ensure the chime rings and lights up.



04 Using the Chime

1. Press the Ringtone button to cycle through available chimes, or select a chime in the app.
 2. Press the Volume button to adjust the chime volume, or adjust it in the app.
- Volume Levels:** Mute, Low, Moderate, Loud, Very Loud.




NOTE:

1. When set to Low or Very Loud, you will hear two beeps.
2. When set to Mute, the chime will flash without sound.

Reset the Chime

1. Power off the chime.
2. Press and hold the Volume button, then plug the chime into a power outlet. Keep holding the button until you hear 10 slow beeps followed by 4 fast beeps, indicating the chime has been successfully reset.



05 Specifications

Hardware Features

Input: 100–240VAC, 50–60Hz

Number of Ringtones: 10

Volume Levels: 0–4 (0–100 dB)

General

Material: ABS+PC

Operating Temperature: –20°C to 55°C (–4°F to 131°F)

Operating Humidity: 10%–90%

06 Important Safety Instructions

Please read the instructions carefully before using the device.

1. Replace only with the same or equivalent type of accessories recommended by Reolink.
2. Do not use the device in an environment that exceeds the recommended temperature range.
3. Do not use the device in an environment that exceeds the recommended humidity range.
4. Do not attempt to disassemble, repair, or alter the device by yourself.
5. Always follow the local safety laws and regulations when using the device.
6. The device contains (or comes with) small components, small plastic elements, and other small parts that may cause choking hazards. Keep the device and its accessories out of reach of children. Consult a physician immediately if small parts are swallowed.
7. The device contains (or comes with) cables or cords that may cause strangulation hazards. Keep the device and its accessories out of reach of children.
8. The product doesn't include assistive features. Customers with disabilities can use devices with assistive features, like computers or smartphones with text-to-speech tools, for accessibility. For individuals with visual or physical impairments, professional help may be needed for installation. Once installed, the product can be controlled entirely via the app.

07 Legal Disclaimer

To the maximum extent permitted by applicable law, this document and the product described, with its hardware, software, firmware, and services, are delivered on an “as-is” and “as-available” basis, with all faults and without warranty of any kind. Reolink disclaims all warranties, express or implied, including but not limited to, warranties of merchantability, satisfactory quality, fitness for a particular purpose, accuracy, and non-infringement of third-party rights. In no event will Reolink, its directors, officers, employees, or agents be liable to you for any special, consequential, incidental or indirect damages, including but not limited to damages for loss of business profits, business interruption, or loss of data or documentation, in connection with the use of this product, even if Reolink has been advised of the possibility of such damages.

To the extent permitted by applicable law, your use of the Reolink products and services is at your sole risk and you assume all risks associated with internet access. Reolink does not take any responsibilities for abnormal operation, privacy leakage or other damages resulting from cyber attacks, hacker attacks, virus inspections, or other internet security risks. However, Reolink will provide timely technical support if required.

The laws and regulations related to this product vary by jurisdiction. Please check all relevant laws and regulations in your jurisdiction before using this product to ensure that your use conforms to the applicable law and regulation. During the use of the product, you must comply with relevant

local laws and regulations. Reolink is not responsible for any illegal or improper use and its consequences. Reolink is not liable in the event that this product is used with illegitimate purposes, such as third-party rights infringement, medical treatment, safety equipment, or other situations where the product failure could lead to death or personal injury, or for weapons of mass destruction, chemical and biological weapons, nuclear explosion, and any unsafe nuclear energy uses or anti-humanity purposes. In the event of any conflicts between this manual and the applicable law, the latter prevails.

08 Notification of Compliance



SIMPLIFIED EU AND UK DECLARATION OF CONFORMITY

Hereby, REOLINK TECHNOLOGY PTE. LTD. declares that the radio equipment type [refer to the cover of the Operational Instructions] is in compliance with Directive 2014/53/EU. The full text of the EU and UK declaration of conformity is available at the following internet address:

<https://reolink.com/certification-compliance/>

RF exposure information: The Maximum Permissible Exposure (MPE) level has been calculated based on a distance of 20cm between the device and the human body. To maintain compliance with RF

exposure requirement, use product that maintain a 20cm distance between the device and human body.

(a)the equipment does not have a standby mode or other equivalent state in terms of energy efficiency requirements, power management function or the ability to deactivate wireless network connections mode;

(b)the power consumption of the equipment is likely to be higher than other equipment models meeting these functional requirements.

Sub 1G Operating Frequency

OPERATING FREQUENCY :
868MHz RF Power:≤10dBm(EIRP)



Correct Disposal of This Product

This symbol indicates that this electrical or electronic device must not be treated as household waste at the end of its life; instead, it requires separate collection. Free collection points for recycling and reuse are available in your local area. Please contact your municipal authority for these locations. Upon request, authorized retailers may accept up to three old devices free of charge at or near the point of sale. You are required to separate old equipment from general municipal

waste. Before returning the device, please remove any batteries, accumulators, or lamps that are not permanently built-in and can be removed without damage. If the device contains personal data, you are responsible for deleting it prior to disposal.

Limited Warranty

This product comes with a 2-year limited warranty that is valid only if purchased from Reolink Official Store or a Reolink authorized reseller. Learn more: <https://reolink.com/warranty-and-return/>.

Terms and Privacy

Use of the product is subject to your agreement to the Terms of Service and Privacy Policy at reolink.com

Technical Support

If you need any technical help, please visit our official support site and contact our support team before returning the products, <https://support.reolink.com>.

Terms of Service

By using the Product Software that is embedded on the Reolink product, you agree to the terms&conditions between you and Reolink. Learn more: <https://reolink.com/terms-conditions/>

Trademarks Acknowledgement

“Reolink” and other Reolink’s trademarks and logos are the properties of Reolink. Other trademarks and logos mentioned are the properties of their respective owners.