


JVC HA-FY6M-BE



Using the remote control unit

Audio/phone operation (example for iPhone)

For audio operation

To play or pause a track	Press once
To skip to the next track	Press twice
To return to the previous track	Press three times

For phone operation

To answer or end a call	Press once
-------------------------	------------

- For some mobile phones, you may not be able to use some or all functions depending on the specifications of the mobile phone itself.
- This unit supports smartphones with a 4-pole plug headphone jack. Any devices with a 3.5 mm 3-pole or 2-pole plug headphone jack are not supported.

Gebruik van de afstandsbediening

Bediening van audio/telefoon (voorbeeld voor iPhone)

Voor audiobediening

Weergave of pauzeren van een fragment	Druk eenmaal
Verspringen naar het volgende fragment	Druk tweemaal
Verspringen naar het voorgaande fragment	Druk driemaal

Voor telefoonbediening

Beantwoorden of eindigen van een gesprek	Druk eenmaal
--	--------------

- Met dit toestel wordt de werking van alle functies van de afstandsbediening niet gegarandeerd.
- Deze hoofdtelefoon is geschikt voor smartphones met een 4-polige hoofdtelefoonaansluiting. Apparaten met een 3,5mm, 3-polige of 2-polige hoofdtelefoonaansluiting kunnen niet worden gebruikt.

English

Nederlands