SONY

Gaming Keyboard

Reference Guide

INZONE KBD-H75 Model: YY2992

https://rd1.sony.net/help/mdr/2992/h_zz/

A



5-067-451-**31**(1)
©2025 Sony Corporation
Printed in China

* 5 0 6 7 4 5 1 3 1 * (1)

Model: YY2992

The term “product” in this document refers to the unit or its accessories.

The nameplate and important information concerning safety are attached in the following locations:
See Fig. **A**

Notice for customers: the following information is only applicable to products sold in countries/regions applying EU directives and/or UK applying relevant statutory requirements.

Reduction in the Use of Hazardous Substances in Electrical & Electronic Equipment (Applicable in Republic of India)
This product and its components, consumables, parts or spares comply with the hazardous substances restriction of India’s E-Waste (Management) Rules. The maximum allowable concentrations of the restricted substances are 0.1% by weight in homogenous materials for Lead, Mercury, Hexavalent Chromium, Polybrominated Biphenyls (PBB) and Polybrominated Diphenyl Ethers (PBDE), and 0.01% by weight in homogenous materials for Cadmium, except for the exemptions specified in Schedule II of the aforesaid Rules.

The unit is not waterproof. If water or foreign matter enters the unit, it may result in fire or electric shock. If water or foreign matter enters the unit, stop use immediately and consult your nearest Sony dealer. In particular, be careful in the following cases.

- When using the unit near a container filled with water
  Be careful not to get water on the unit.
- When using the unit while you are perspiring
  Touching the unit with wet hands can get the unit wet.

Never insert the USB plug when the unit or cable is wet. If the USB plug is inserted while the unit or cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter on the unit or cable, and cause abnormal heat generation or malfunction.

This product has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

This product has magnet(s). Swallowing magnet(s) could cause serious harm, such as choking hazard or intestinal injuries. If magnets (or a magnet) were swallowed, consult a doctor immediately. Keep this product away from children or other supervised individuals to prevent accidental ingestion.

There is a danger that small parts may be swallowed. After use, store in a location out of reach of small children.

Precautions

The URL on the cover will help you access the help guide that describes useful notes or procedures in details.

About the key layout

- The key layout of the unit is configured in the US layout. When connecting the unit to a computer that has a different keyboard layout, the keys may not work correctly. In that case, adjust the key settings on your computer accordingly.

About the volume dial

- You can use the volume dial in the upper right corner of the unit to adjust the volume on the connected computer. This does not change the volume of a connected headset. If you are using a Sony gaming headset, the INZONE Hub app allows you to use the volume dial to adjust the volume of the headset.

About the USB cable

- Be sure to use the supplied USB Type-C cable.
- While connecting the USB cable, do not apply excessive force to the connection part.
- When connecting or disconnecting the USB cable, do not apply excessive force, such as by pulling the cable, and connect or disconnect the connector straight to the port to be connected.
- If the USB cable connector is deformed, such as by it being bent, stop use immediately.

Other notes

- Do not subject the unit to excessive shock.
- Wipe the plug occasionally with a dry, soft cloth.
- Wipe the exterior clean with a soft, dry cloth.
  - For stubborn stains, moisten a soft cloth with warm water and then wipe.
  - Do not use detergents, alcohol, or similar agents, as these may cause discoloration or deterioration.
  - To remove dust, use a soft brush or similar and gently wipe clean.
- Do not apply weight or pressure to the unit for long periods, including when it is stored, as it may cause deformation.
- If you experience discomfort while using the unit, stop using it immediately.
- Avoid extended usage or storage in high humidity or temperatures above 60 °C. It may cause failure.
- If you have any questions or problems concerning this unit that are not covered in this manual, please consult your nearest Sony dealer.

Replacement parts: Rubber feet
Please consult your nearest Sony dealer for information about replacement parts.

Location of the serial number label

See Fig. **A**

Specifications

Gaming Keyboard (YY2992)

Size:
75% tenkeyless
Key layout:
US layout
Connection type:
Wired
Interface:
USB 2.0
Connector:
USB Type-C
Power source:
USB bus power compliant (5 V, 500 mA)
Compatible OS:
Windows® 10 or later
Operating temperature:
0 °C to 40 °C
Switch Type:
Magnetic switches
Polling rate:
8 000 Hz
Keycaps:
Double shot PBT keycaps
Media key:
Volume dial
Onboard memory function:
Yes
Supported software:
INZONE Hub
Dimensions:
Approx. 318.8 mm × 37.5 mm × 132.3 mm (width × height × depth)
Mass:
810 g

Others

Included items:
Gaming Keyboard (1)
USB Type-C® cable (USB-A to USB-C®) (1)
Documents (1 set)

Design and specifications are subject to change without notice.

Trademarks

- Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
- Sony and INZONE are registered trademarks or trademarks of Sony Group Corporation or its affiliates.
- All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, ™ and ® marks are not specified.

Licenses

- Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.
- Network services, content and the (operating system and) software of this product may be subject to individual terms and conditions and changed, interrupted or discontinued at any time and may require fees, registration and credit card information.